

## Parts list E 10

Code List € Price

Outside basket	1801	
Inside basket	P1802	
Complete cover	1803	
Cover w/ o small cover, handle & gear	1804	
Handle only	1809	
Axle for outside basket	1810	
Small cover with handle & gear	1812	
Axle	1814	
Small cover (w/ o handle & drive gear)	2805	
Perforated drive gear + pin	2806	
Large gear	2807	
Small gear	2808	
Pin	2811	
Axle for drive & small gear	2813	
Set of gears (2806, 2807, 2808, 2811)	2815.1	
Handle screws (4)	9014	
Orange plastic nuts (4)	9014.P	
Stainless steel pins (M4x25) (4)	9014.G	

## Parts list E 20

Code List € Price

Outside basket	2801	
Inside basket	P2802	
Complete cover	2803	
Cover w/ o small cover, handle & gear	2804	
Small cover (w/ o handle & drive gear)	2805	
Perforated drive gear + pin	2806	
Large gear	2807	
Small gear	2808	
Handle only	2809	
Axle for outside basket	2810	
Pin	2811	
Small cover with handle & gear	2812	
Axle for drive & small gear	2813	
Axle	2814	
Set of gears (2806, 2807, 2808, 2811)	2815.1	
Handle screws (4)	9014	
Orange plastic nuts (4)	9014.P	
Stainless steel pins (M4x25) (4)	9014.G	

